

WORK SMARTER... NOT HARDER!

SERVICE TAGS

80 X 30 WITH HOLE



410004	A/C SHUT DOWN PRESSURE SWITCH	410065	BRIGADE ALARM
410005	AIR BLEED	410070	BRIGADE ALARM FLOW SWITCH OPEN
410010	ALARM GONG	410075	BRIGADE ALARM LOCK OPEN
410015	ALARM VALVE	410076	DO NOT OPERATE
410020	AUTO JACKING PUMP DISCHARGE VALVE LOCK OPEN	410079	DELUGE SYSTEM
410025	AUTO JACKING PUMP DISCHARGE	410080	DIESEL PUMP PRESSURE SWITCH
410030	AUTO JACKING PUMP SUCTION	410085	DIESEL PUMP NO.1 PRESSURE
410035	AUTO JACKING PUMP SUCTION VALVE LOCK OPEN	410090	DIESEL PUMP NO.2 PRESSURE
410040	ANNUBAR	410095	DIESEL PUMP NO.3 PRESSURE
410045	ANNUBAR TEST LINE	410100	DIRECT BRIGADE ALARM PRESSURE
410050	ANNUBAR VALVE LOCK OPEN	410105	DRAIN TEST VALVE CLOSED
410055	AUTO START LOCK OPEN	410110	DRAIN VALVE CLOSED
410060	AUTO START LOCK CLOSED	410115	ELECTRIC PUMP PRESSURE SWITCH

BRISBANE STH

31 LENSWORTH ST
COOPERS PLAINS
T: 07 3064 1046

BRISBANE NTH

90 NORTHLINK PLACE
VIRGINIA
T: 07 3865 7554

GOLD COAST

9 ENERGY CRESENT
MOLENDINAR
T: 07 5603 3712

SHEET METAL

ACACIA RIDGE
T: 07 3064 1046

FABRICATION

COOPERS PLAINS
T: 07 3064 1046

WORK SMARTER... NOT HARDER!

SERVICE TAGS

80 X 30 WITH HOLE



410120	EVACUATION SWITCH	410181	LARGE - FIRE MAIN USE 003
410125	EVACUATION PRESSURE SWITCH	410182	LARGE - FHR SERVICE USE 003
410130	EXIT	410185	FLOW SWITCH
410135	FIRE MAIN VALVE LOCK OPEN	410190	FLOW SWITCH TEST VALVE
410140	FIRE MODE PRESSURE SWITCH	410195	FLOW SWITCH TEST VALVE L/OPEN
410145	FIRE INDICATOR PANEL	410200	FLOW SWITCH TEST VALVE L/CLOSED
410150	FIRE RING MAIN PRESSURE	410205	FLOW SWITCH TEST DRAIN
410155	FIRE MAIN PRESSURE SWITCH	410210	HYDRANT DIESEL PUMP
410160	FIRE HYDRANT DIESEL PUMP	410215	INSTALLATION PRESSURE NO.1
410165	FIRE PUMP MANUAL	410220	INSTALLATION PRESSURE NO.2
410170	FIRE SPRINKLER DIESEL PUMP	410225	INSTALLATION PRESSURE NO.3
410175	FIRE SERVICE VALVE CLOSED ONLY	410230	INSTALLATION PRESSURE NO.4
410180	FIRE SPRINKLERS	410235	INSTALLATION PRESSURE NO.5

BRISBANE STH

31 LENSWORTH ST
COOPERS PLAINS
T: 07 3064 1046

BRISBANE NTH

90 NORTHLINK PLACE
VIRGINIA
T: 07 3865 7554

GOLD COAST

9 ENERGY CRESENT
MOLENDINAR
T: 07 5603 3712

SHEET METAL

ACACIA RIDGE
T: 07 3064 1046

FABRICATION

COOPERS PLAINS
T: 07 3064 1046

WORK SMARTER... NOT HARDER!

SERVICE TAGS

80 X 30 WITH HOLE



410240	INSTALLATION PRESSURE NO.6	410305	JACKING PUMP SUCTION VALVE
410245	INSTALLATION PRESSURE NO.7	410310	LOCAL ALARM LOCK OPEN
410250	INSTALL PRESSURE	410315	LOCK OPEN
410255	INSTALL PRESSURE SWITCH	410320	LOCK CLOSED
410260	ISOLATION VALVE	410325	MAIN STOP VALVE
410265	ISOLATION VALVE LOCK CLOSED	410330	MAIN STOP VALVE LOCK OPEN
410270	ISOLATION VALVE LOCK OPEN	410335	MAIN STOP VALVE LOCK CLOSED
410275	JACKING PUMP PRESSURE	410340	MANIFOLD PRESSURE
410280	JACKING PUMP	410345	PRIMARY PUMP
410285	JACKING PUMP DISCHARGE VALVE	410350	PRESSURE SWITCH
410290	JACKING PUMP DISC VALVE L/OPEN	410355	PULL TO STOP
410295	JACKING PUMP LOCK OPEN	410360	PUMP DISCHARGE ISOLATION
410300	JACKING PUMP PRESSURE SWITCH	410365	PUMP DISCHARGE PRESSURE

BRISBANE STH

31 LENSWORTH ST
COOPERS PLAINS
T: 07 3064 1046

BRISBANE NTH

90 NORTHLINK PLACE
VIRGINIA
T: 07 3865 7554

GOLD COAST

9 ENERGY CRESENT
MOLENDINAR
T: 07 5603 3712

SHEET METAL

ACACIA RIDGE
T: 07 3064 1046

FABRICATION

COOPERS PLAINS
T: 07 3064 1046

WORK SMARTER... NOT HARDER!

SERVICE TAGS

80 X 30 WITH HOLE



410370	PUMP SUCTION ISOLATION VALVE	410425	SPRINKLER FLOW SWITCH TEST
410375	PUMP SUCTION PRESSURE	410430	SPRINKLER FLOW SWITCH TEST L/O
410380	REGULATING VALVE	410435	SPRINKLER FLOW SWITCH TEST L/C
410385	REMOTE TEST	410440	SPRINKLER REMOTE TEST VAL L/C
410390	REMOTE TEST VALVE CLOSED	410445	SPRINKLER ISOLATION VALVE L/C
410395	SECONDARY PRESSURE	410450	STOP VALVE LOCK OPEN
410400	SECONDARY PUMP	410455	SUPPLY PRESSURE
410405	SERVICE TAG YELLOW WITH RING	410465	TANK TOP UP LOCK OPEN
410410	POUCH FOR ABOVE SERVICE TAG	410470	TANK FILL VALVE
410415	SPARE SPRINKLERS	410475	TEST DRAIN
410416	SPRINKLER DIESEL PUMP	410480	TEST VALVE LOCK CLOSED
410417	SPRINKLER ELECTRIC PUMP	410485	TEST VALVE LOCK OPEN
410420	SPRINKLER DIESEL PUMP (150 X 100)	410490	TEST POINT

BRISBANE STH

31 LENSWORTH ST
COOPERS PLAINS
T: 07 3064 1046

BRISBANE NTH

90 NORTHLINK PLACE
VIRGINIA
T: 07 3865 7554

GOLD COAST

9 ENERGY CRESENT
MOLENDINAR
T: 07 5603 3712

SHEET METAL

ACACIA RIDGE
T: 07 3064 1046

FABRICATION

COOPERS PLAINS
T: 07 3064 1046

WORK SMARTER... NOT HARDER!

SERVICE TAGS

80 X 30 WITH HOLE



410495	TOWNS MAIN PRESSURE
410500	TOWNS WATER
410505	WATER METER
410510	WASTE & TEST VALVE
410515	WINDOW DRENCH ISOLATION VALVE
410575 100 X 40	FIRE HOSE REEL SERVICE SECURE OPEN (USE ONLY 003 FIRE SERVICE LOCK)
410580 100 X 40	FIRE MAIN VALVE SECURE OPEN (USE ONLY 003 FIRE SERVICE LOCK)
411069 135 X 30	FIRE SERVICE VALVE CLOSE ONLY TO SERVICE FIRE HOSE REEL

ROUND IDENTIFICATION TAGS

415021	TAG NUMBER 1
415022	TAG NUMBER 2
415023	TAG NUMBER 3
415024	TAG NUMBER 4
415025	TAG NUMBER 5
415026	TAG NUMBER 6
415027	TAG NUMBER 7
415028	TAG NUMBER 8
415029	TAG NUMBER 9
415031	KIT 01 - 06
415032	KIT 01 - 12
415033	KIT 01 - 18
415034	KIT 01 - 24
415035	KIT 01 - 48



40 X 40

BRISBANE STH

31 LENSWORTH ST
COOPERS PLAINS
T: 07 3064 1046

BRISBANE NTH

90 NORTHLINK PLACE
VIRGINIA
T: 07 3865 7554

GOLD COAST

9 ENERGY CRESENT
MOLENDINAR
T: 07 5603 3712

SHEET METAL

ACACIA RIDGE
T: 07 3064 1046

FABRICATION

COOPERS PLAINS
T: 07 3064 1046